

SAVAGE LIGHT
INDUSTRIES

SUKHOI SU-27

TECH NOTES

B7B-2



Savage Light Industries

19041 Singingwood Circle • Trabuco Canyon • CA • 92679
949-589-7120 • Info@SavageLight.com • www.SavageLight.com
Copyright © 2009 • All Rights Reserved

Savage Light Industries
SUKHOI CY-27
T E C H N O T E S
B7B-2

During the construction of the Su-35/Su-37 Conversion Kit we discovered an error in the size of the inlet duct holes in bulkhead B7B-2.

While this error can be corrected when fitting the inlets ducts to the model, it's easier to enlarge the holes before beginning construction.

This document contains information about how to correct the error in the Su-27 kit.



Photo 1

- 1. Cut from the sheet one bulkhead B7B-2. (1/8" lite ply) Pull the inlet ducts from the poly shipping bag. Using sandpaper, gently sand the forward opening of the inlet duct to remove any excess fiberglass. Repeat for the other side. (Photo 1)



Photo 2

- 2. Use a pencil and ruler to draw a line that is 1/64" outside the inlet duct opening in B7B-2. Repeat for the other side (Photo 2)



Photo 3

- 3. Use a coping saw or a scroll saw to cut along the lines you drew earlier. Check the fit by inserting the inlet ducts into the opening.. Repeat for the other side. (Photo 3)